
How to Clean Your Smoke Alarm

10 Year Lithium Non-removable Battery Smoke Alarm



1.

Use a soft brush or your vacuum to gently remove all dust and debris every six months. In most cases this can be done from the ground.



2.

Gently wipe the detector with a soft damp cloth every six months. Always use a ladder appropriate for the job. Never stand on chair or furniture etc. You can clean all types of alarms in this manner.

NEVER ATTEMPT TO CHANGE A BATTERY IN A 10-YEAR NON-REMOVABLE LITHIUM BATTERY ALARM.

